

# ORION

## ELECTRONIC KITCHEN SCALE

---

**Model: ORION OS-0K22**

## USER'S GUIDE

**ENGLISH**

**GB**

*Dear Customer,*

*Thank you for buying ORION products! Welcome to use!*

*Please read this User's Guide carefully before use and save it.*

*Best regards,*

*ORION ELECTRONICS Team*

*More details: <http://www.orion.ua>*

*Mail to us: [support@orion.ua](mailto:support@orion.ua)*

### Care and Attention

- Put the scale on a clean and flat table.
- The maximum weight of the scale is 2000g, which included the weight before tare.
- To ensure the life of the scale, do not put the scale under wet, hot & cold condition.
- The product belongs to high precision electronic weighing apparatus, please do not press or drop the scale otherwise the scale is easy to damage.
- If the scale surface is dirty, please clean the scale with soft cloth, do not use any chemical detergent and water to get inside the scale.
- The product is for family weighing only, do not use for legal trade.
- If the result appears improperly, please check about whether the batteries and the touch point contact well. Replace for new batteries if not used for a long time already, and then try again

### Specifications

- Equipped with a high precision "stain-gauge" sensor and high capability CPU to ensure the weighing accuracy.
- Capacity: 2kg
- Division: 1g
- Unit: gram
- Low Battery/Overload Indication
- Tare function.
- Auto power off.
- Function Key: (ON/OFF, TARE)
- Power: 2×AAA batteries

## **Power Supply**

Use 2pcs AAA batteries.

When change the batteries, please open the battery cover on the back, put 2pcs AAA batteries in the battery case, then close the battery cover tight.

## **Operating Instructions**

- Take out the scale, and open up the battery cover, install the batteries to the battery case.
- Put the scale on the flat table, and ensure it steady.
- Press the key of “ON /OFF” to power on, after a few second it will show “0g” on the display. If show other digital please press “TARE”.
- Under the weight state, put the object on the scale, LCD will show the weight.
- If some thing is on the scale, you can press the key of “TARE”, LCD show zero. Clear the weight of the object. If you want to weight some more things you can repeat this function.
- After all the above step, take out the object, then LCD will show the object weight that before tare with negative, and at the left side you can see ”-”.
- If don't weight any thing or after when the reading steady it will power off about a few seconds.

## **Low Battery/Overload Indication**

When the scale is over loaded, the “O-Ld” will appear on the display.

When the screen shows “LO”, it means that the power isn't enough; please change the batteries as soon as possible.

Subject to change without notice

Extra information on ORION company web-site [www.orion.ua](http://www.orion.ua)

We take your opinion and offers by E-mail [support@orion.ua](mailto:support@orion.ua)