

INSTRUCTION MANUAL

MECHANICAL BATHROOM SCALE

Model: OS0020M

ENGLISH

GB



Dear customers!

Thank you for purchasing ORION products. Before operation, please read this instruction manual. Save it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- This appliance should be used only for its intended purposes. Any other use of it is wrong and therefore dangerous. Manufacturer is not liable for damages that are the result of improper or incorrect use of the appliance. Under these conditions, the guarantee will be cancelled.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not immerse scale in water.
- Place the scale in an area free from direct sunlight, heating equipment, high humidity, or extreme temperature change.
- Do not leave any objects on top of scale if the product is not to be used during a prolonged period of time.
- Do not allow children to play with this appliance.
- Do not use the appliance outdoors.
- The appliance is not intended for commercial use.

CHARACTERISTICS

- 130kg weight capacity
- Graduation 1kg
- Measures in kilograms
- Compact and stylish design
- Color: green
- Net weight/gross weight: 1,22 kg/1,35 kg
- Product size: 24.3x26.8x4.2cm
- Box size: 28.4x26.4x5.3cm

INSTRUCTION FOR USE AND USEFUL HINTS

- Place the scale on a hard even surface
- Always weigh yourself on the same scale placed on the same floor surface. Uneven floors may affect the readings.
- Always weigh yourself without clothing or footwear, and before meals. The first thing in the morning is the best time.
- Treat your scale with care as it is a precision instrument, do not drop it or jump up or down on it.
- To avoid slipping, make sure your feet are dry before standing on the scale.
- To avoid possible injury, do not stand on the edge of the platform.
- The indicator needle should be set to zero "0" before weighing. To adjust the needle position, turn the knob located on the scale body



Accuracy is guaranteed as the tolerance limit below:

0-65kg	±1.2 digits
>65kg	±2.0 digits

MAINTENANCE

- Wipe dry with a clean cloth
- Do not use abrasive washing powders, steel wool or scouring pads
- Store scale in a cool place
- Do not store the scale in an upright position

PACKAGE CONTENTS

- Mechanical bathroom scale
- User manual
- Guarantee card
- Information card ORION

Subject to change without notice

Extra information on ORION company web-site www.orion.ua

We take your opinion and offers by E-mail support@orion.ua

DEVELOPED BY ORION ELECTRONICS LTD

(29 Jászberényi út, Budapest 1106, HUNGARY, EUROPE)

ASSEMBLED IN P.R.C. UNDER STRICT CONTROL OF ORION ELECTRONICS LTD
(HUNGARY, EUROPE)

CERTIFIED AND APPROVED BY ORION ELECTRONICS LTD (HUNGARY,
EUROPE)

